

# Why is ITER so darn big? (or Turbulence and Transport in Magnetized Plasmas)




Troy Carter
Dept. of Physics and
Astronomy
UCLA

LANL Plasma Physics Summer School Lecture
August 1, 2006

#### Reminder: Fusion energy only effecient with confinement









- Coulomb barrier makes cross-section appreciable only at moderate energy
- Scattering cross-section >> fusion cross-section (beam fusion will not work)
- Need to confine a hot plasma to allow multiple scattering collisions per fusion (thermonuclear fusion)

# Thermonuclear fusion in a hot, confined plasma




 Three confinement schemes: Gravitational (stars), magnetic (e.g. tokamak), inertial (laser fusion, hydrogen bomb)

### Magnetic confinement of plasma




- Astrophysical example of magnetic confinement: prominence in the solar corona (TRACE satellite)
- Charged particles are confined to magnetic field lines (execute helical orbits around them), BUT no confinement along lines

# The Tokamak: toroidal magnetic confinement




- Toroidal field lines eliminate end losses
- Need helical field to confine charged particles (they drift in curved fields)
- Drive current in the plasma to generate "poloidal field"

### A little history: 1951 Optimism



Lyman Spitzer.



#### Spitzer's fusion reactor: the stellarator


 $\mathbf{B} \sim 50 \mathrm{KG}$ .

T > 10 keV $n \sim 10^{14} \text{cm}$ 

Minor radius 50cm.


Tube length 40-50m.

DT fusion Power. 150MW



Why didn't it work? Transport (confinement is not perfect)

#### Fusion Energy Balance in a Magnetic Bottle



- External heating + Alpha heating has to balance losses due to transport and radiation
- If losses are too big, heating power can be bigger than fusion power in order to maintain temperature


### A few definitions

$$P_{TRANSPORT} = rac{nTV}{ au_E}$$
 Energy Confinement Time.

$$Q = \frac{P_{FUSION}}{P_{HEAT}} = \frac{P_{NEUTRONS} + P_{\alpha}}{P_{HEAT}} = \frac{5P_{\alpha}}{P_{HEAT}}$$

- Q=I is breakeven, Q=5 is 50% alpha heated, and Q=infinity is ignition (no external heat required)
- World record Q's: TFTR Q=0.27, JET Q=0.61
- Transport determines confinement time, which in turn sets required heating power and therefore Q

# Classical (collisional) transport is predicted to be very small



- Charged particles collide with one another, causing a change in direction and a "step" across the magnetic field
- Many collisions: random-walk diffusion
- But collisions are rare in a hot plasma (and step size is small), Spitzer's reactor should have been good enough for ignition!


# Transport by turbulence can be significantly bigger than classical transport

- Not quite right: Particles "scatter" off of electric fields associated with collective oscillations in the plasma (much longer range than classical collisions)
- Really: ExB motion driven by fluctuations causes transport (for electrostatic modes)
- What causes fluctuations? Unstable plasma waves driven by free energy sources in the plasma


#### Gradient-driven instabilities

- Global thermodynamic equilibrium would require the plasma to have a flat temperature and density profile (same T as wall) -- any departure from this represents a source of free energy
- Motions in the plasma which attempt to flatten temperature profile (e.g. mixing) can tap this free energy source (can be unstable)


### Simple physical picture of Gradient/ Curvature driven instability



#### Massively parallel simulations of tokamak turbulence




- Ion Temperature Gradient driven turbulence (ITG)
- Convective cells carry heat and particles from core to edge much faster than collisions



### Turbulent diffusion estimates


- Mixing length estimate: step size is correlation length (~size of eddy), time step is correlation time (or "eddy turnover time")
- Spatial step ~10  $\rho_i$ , time step ~1/ $\omega$  (linear mode frequency) (<< collision time scale)
- Leads to diffusion coefficent a couple of orders of magnitude (or more!) bigger than classical diffusion
- Confinement gets worse with increasing heating power ("L-mode"), as the step size increases

# Turbulence and transport suppression in H-mode




- Spontaneous confinement improvement with increased heating power
- Fluctuations in edge reduced, recycling reduced
- Edge transport barrier (and "pedestal") observed
- Sheared flow (radial E field) develops simultaneously

# Sheared flow at edge coincident with turbulence reduction



- Shear layer forms at H-mode transition
- Turbulence suppressed in the region of the shear layer
- Transport significantly reduced, "pedestal" forms


# Success in theoretical understanding: suppression of turbulence by sheared flow in barrier




 Sheared flow rips eddies apart, smaller eddies means shorter transport steps Code: GYRO

Authors: Jeff Candy and Ron Waltz


### Shear Suppression on The Large Plasma Device (LAPD) at UCLA






- 17m long, Im ID cylindrical chamber (plasma < 60cm), Barium Oxide coated nickel cathode source (pulsed, 10 ms, 1 Hz rep rate)
- Typical parameters:  $n_e \sim 10^{12}$  cm<sup>-3</sup>,  $T_e \sim 10$ eV,  $T_i \sim 1$ eV, 400G < B < 2kG
- Working gases: He, Ne, Ar, H
- US DOE/NSF sponsored user facility: <a href="http://plasma.physics.ucla.edu/bapsf">http://plasma.physics.ucla.edu/bapsf</a>


#### Driven shear flow with biased rotation in LAPD




### Biasing creates electric fields in the edge and "cleans up" edge in visible images




#### Edge profiles steepen during biased rotation



- Triple Langmuir probe measured density, flow measurements using 6 face Gundestrup (Mach) probe
- Measured flow consistent with ExB (E ~ 100 V/m), observed shearing rate is comparable to ω\* (~20kHz)
- Threshold bias for steepening is observed
- Dynamics: profile change on transport timescale (movie)




#### Gradient scale length, fluctuation amplitude decrease at threshold




- Past threshold,  $L_n$  decreases dramatically, but saturates at ~ 2cm  $(\rho_s \sim 1 \, \text{cm})$
- Peak E<sub>⊙</sub> fluctuation amplitude drops at first, but increases again at higher bias
- Product of magnitudes of  $I_{sat}$  and  $E_{\Theta}$  fluctuations decreases by a factor of 5

#### Turbulent flux is suppressed and reversed with increasing bias




- Suppression of flux is coincident with profile steepening
- Reversal of transport flux in shear flows theoretically predicted [e.g. Terry] observed in other biased experiments [e.g Shats, Boedo]

#### Cross phase changes dramatically during biased rotation




- FFT spectrum: Low f reduction, doppler shift
- Coherency increases with bias
- Cross phase reduced then reversed

#### 2D correlation functions sheared during biased rotation




- Correlation function sheared, with significant azimuthal correlation
- Radial correlation length is reduced, but only slightly




### Shear suppression of turbulence is accepted explanation of H-mode, but what drives the flow?

- Very important unsolved problem (future work for you?)
- Turbulence can self-regulate by nonlinearly driving flow (zonal flow, driven by Reynolds stress). Is this the L to H mechanism?
- Flows could spontaneously develop due to changes in poloidal flow damping [Shaing, et al show bifurcation]
- Radial electric field due to orbit loss, etc?
- Another important question: What sets the height of the pedestal? [This sets ultimate fusion performance!!]


### Conflicting data in tokamaks on turbulent driven flow





 DIII-D shows evidence at transition [Moyer, Tynan, et al], NSTX does not [White, Zweben, Burin, Carter, et al]

### Data from small experiment shows strong evidence for turbulence driven flow



 CSDX [Holland, Tynan, et al] directly measured turbulent drive and compared to flow measurements (above)

### Conclusion

- Answer to the original question: Why is ITER so darn big?
- To make confinement time large enough!

  Transport is roughly at the same rate as in smaller machines, but has further to go, meaning longer confinement time (dumb way to make a reactor work!)
- Challenge for you: understand and control turbulence and transport so that we can build smaller, more economical fusion plants